

Volume Material

? Unknown Attachment

Adding Material

In the MAT pane, create a PxrMaterialBuilder, dive inside and create a [PxrVolume](#) BxDF

Assigning Material

Drag your PxrVolume VOP to the Material parameter of your volume OBJ.

? Unknown Attachment



For **deformed** volume, velocity and density must be wired using PxrPrimVar. This is because 'v' in VDB is a built-in variable.

? Unknown Attachment

Unable to render {include} The included page could not be found.